

# ATV Model

## Parts Sheet



- |                   |                       |
|-------------------|-----------------------|
| 1 – ATV Carrier   | 2 – ¾ “ locking bolts |
| 1 – 5’ Main Frame | 2 – pins              |
| 2 – uprights      | 2 – hair pins         |
| Wings             | 4 – 2” round u-bolts  |
| Wick Tubes        | 4 – flat plates       |
| 2 – ½ x 2 bolts   | 6 – 3” round u-bolts  |
| 2 – ½” lock nuts  | 20 – 3/8 flange nuts  |

Vogels Wick Weeders Ltd  
*Paul & Marian Vogels*  
43420 Staffa Road, R.R. # 2 Kippen, Ontario, Canada N0M 2E0  
[www.vogelswickweeders.com](http://www.vogelswickweeders.com)  
[pmvogels@tcc.on.ca](mailto:pmvogels@tcc.on.ca)

phone 519-522-1030

fax 519-522-1040



## ATV Assembly Instructions

- The front carrier is mounted onto the front carrier of the ATV. It is fastened on with four 2" round u-bolts, 4 small flat plates and 3/8 flange nuts.
- Bolt the 2 uprights onto the main 5' frame with 2 - 1/2 x 2" bolts and 1/2" lock nuts. Bolt them onto the back side of the frame.
- The uprights then slide into the front carrier. They are fastened on with 2 - locking bolts for easy height adjustment.
- The wings slide into the main 5' section and are held there by a pin and hair pin. (If you have a 5' model, skip this section)
- Slip the 3" round u-bolt over the wick tube and fasten with 3/8 flange nuts. The ropes on the wick tubes face straight ahead. Fill caps positioned at the top of the wick tube. When fastening be sure not to over tighten, it should be snug but the pipe should not indent.
- For transport pull the wings off and slide them down the 2 uprights.

### Optional:

There is a pressure system available for the ATV units. This is only necessary in a very heavy infestation of weeds.